

EMISSION CONTROL SYSTEMS

CONTENTS

	page		page
EVAPORATIVE EMISSION CONTROLS	1	EXHAUST EMISSION CONTROLS	9

GENERAL INFORMATION

Throughout this group, references may be made to a particular vehicle by letter or number designation.

The Introduction Section at the front of this manual contains a chart showing the breakdown of the designations.

EVAPORATIVE EMISSION CONTROLS

INDEX


	page		page
Crankcase Vent Filter	8	PCV Valve Test	8
Duty Cycle EVAP Canister Purge Solenoid— 3.0L Engine	6	Positive Crankcase Ventilation (PCV) Systems	7
EVAP Canister Purge Solenoid—Except 3.0L Engine	6	Pressure Relief/Rollover Valve	6
Evaporation Control System	6	Pressure-Vacuum Filler Cap	7
Evaporative Canister	6	Vacuum Schematics	2
		Vehicle Emission Control Information Label	1

VEHICLE EMISSION CONTROL INFORMATION LABEL

All models have a Vehicle Control Information (VECI) Label. Chrysler permanently attaches the label to the middle of the hood (Fig. 1). It cannot be removed without defacing information and destroying the label.

The label contains the vehicle's emission specifications and vacuum hose routings. All hoses must be connected and routed according to the label.

If any difference exists between the VECI label on the vehicle and the example labels in the Service Manual, refer to the label on the vehicle. **The labels shown are examples.**



9025-31

Fig. 1 Underhood Label Location



FEDERAL EMISSION CONTROL INFORMATION LABEL—TYPICAL

CANADA VEHICLE EMISSION CONTROL INFORMATION LABEL—TYPICAL

CHRYSLER CORPORATION XXXXX CATALYST	IMPORTANT VEHICLE INFORMATION		
	THIS VEHICLE CONFORMS TO U.S. EPA REGULATIONS APPLICABLE TO 1993 MODEL YEAR NEW LIGHT-DUTY TRUCKS AT ALL ALTITUDES.		
	*BASIC IGNITION TIMING AND IDLE FUEL/AIR MIXTURE HAVE BEEN PRESET AT THE FACTORY. SEE THE SERVICE MANUAL FOR PROPER PROCEDURES AND OTHER ADDITIONAL INFORMATION.	2.5 LITER PCR2.5T5FGF2 PTASA	SPARK PLUGS .035 in. GAP RN12YC
	ADJUSTMENTS MADE BY OTHER THAN APPROVED SERVICE MANUAL PROCEDURES MAY VIOLATE FEDERAL AND STATE LAWS. CAUTION : APPLY PARKING BRAKE WHEN SERVICING VEHICLE.	IDLE TIMING BTC	MAN 12° AUTO 12° NO OTHER ADJUSTMENTS NEEDED FAMILY NO _x EMISSION LIMIT 1.2

9325-49

CHRYSLER CANADA XXXXX	VEHICLE EMISSION CONTROL INFORMATION		
	THIS VEHICLE WAS BUILT FOR SALE IN CANADA AND WAS DESIGNED TO MEET THE EMISSION REQUIREMENTS OF THE CANADA MOTOR VEHICLE SAFETY ACT. IT WAS NOT DESIGNED TO COMPLY WITH THE REQUIREMENTS OF OTHER COUNTRIES.		
	*BASIC IGNITION TIMING AND FUEL INJECTION MIXTURE HAVE BEEN PRESET AT THE FACTORY. ADJUSTMENTS SHOULD NOT BE MADE DURING ROUTINE SERVICE. CAUTION: APPLY PARKING BRAKE WHEN SERVICING VEHICLE	2.5 LITER	SPARK PLUGS 0.9mm GAP RN12YC
	*LE CALAGE DE L'ALLUMAGE INITIAL ET LE MÉLANGE D'INJECTION D'ESSENCE ONT ÉTÉ PRÉRÉGLÉS À L'USINE. N'EFFECTUEZ AUCUN RÉGLAGE LORS DE TRAVAUX D'ENTRETIEN RÉGULIERS. AVERTISSEMENT: SERREZ LE FREN DE STATIONNEMENT POUR FAIRE L'ENTRETIEN OU LA RÉPARATION DU VÉHICULE.	IDLE TIMING BTC	MAN 12° AUTO 12° FAMILY NO _x EMISSION LIMIT 1.1
RENSEIGNEMENTS RELATIFS AU SYSTÈME ANTIPOLLUTION LE PRÉSENT VÉHICULE A ÉTÉ FABRIQUÉ POUR ÊTRE VENDU AU CANADA ET IL A ÉTÉ CONÇU DE MANIÈRE À SE CONFORMER AUX NORMES ANTIPOLLUTION DE LA LOI SUR LA SÉCURITÉ DES VÉHICULES AUTOMOBILES DU CANADA. IL N'EST PAS DESTINÉ À SE CONFORMER AUX NORMES D'AUTRES PAYS.			
*LE CALAGE DE L'ALLUMAGE INITIAL ET LE MÉLANGE D'INJECTION D'ESSENCE ONT ÉTÉ PRÉRÉGLÉS À L'USINE. N'EFFECTUEZ AUCUN RÉGLAGE LORS DE TRAVAUX D'ENTRETIEN RÉGULIERS. AVERTISSEMENT: SERREZ LE FREN DE STATIONNEMENT POUR FAIRE L'ENTRETIEN OU LA RÉPARATION DU VÉHICULE.			
		2.5 LITER	SPARK PLUGS 0.9mm GAP RN12YC
		RÉGLAGE DU RALENTI* DISTRIBUTION AV P.H.	MAN 12° AUTO 12° LIMITE DES GAZ D'ÉCHAPPEMENT NO _x DU GROUPE MOTEUR 1.1

9325-47

CALIFORNIA VEHICLE CONTROL INFORMATION LABEL—TYPICAL


VACUUM SCHEMATICS

If any difference exists between the schematic on the vehicle's VECI label and the vacuum schematics in the Service Manual, refer to the VECI label.

TWC, H02S, TBI OBD EXEMPT CHRYSLER CORPORATION XXXXX CATALYST	IMPORTANT VEHICLE INFORMATION		
	THIS VEHICLE CONFORMS TO U.S. EPA REGULATIONS APPLICABLE TO 1993 MODEL YEAR NEW LIGHT-DUTY TRUCKS AND IS CERTIFIED FOR SALE IN THE STATE OF CALIFORNIA WITH A FEDERAL EMISSION CONTROL SYSTEM.		
	*BASIC IGNITION TIMING AND IDLE FUEL/AIR MIXTURE HAVE BEEN PRESET AT THE FACTORY. SEE THE SERVICE MANUAL FOR PROPER PROCEDURES AND OTHER ADDITIONAL INFORMATION.	2.5 LITER PCR2.5T5FGF2 PTASA	SPARK PLUGS .035 in. GAP RN12YC
	ADJUSTMENTS MADE BY OTHER THAN APPROVED SERVICE MANUAL PROCEDURES MAY VIOLATE FEDERAL AND STATE LAWS. CAUTION : APPLY PARKING BRAKE WHEN SERVICING VEHICLE.	IDLE TIMING BTC	MAN 12° AUTO 12° NO OTHER ADJUSTMENTS NEEDED FAMILY NO _x EMISSION LIMIT 1.2


9325-48

9325-50




ENGINE VACUUM SCHEMATIC—2.5L ENGINE





9325-51

ENGINE VACUUM SCHEMATIC—3.0L ENGINE



9325-52

ENGINE VACUUM SCHEMATIC—3.3L ENGINE

EVAPORATION CONTROL SYSTEM

The evaporation control system prevents the emission of fuel tank vapors into the atmosphere. When fuel evaporates in the fuel tank, the vapors pass through vent hoses or tubes to a charcoal canister. The canister temporarily holds the vapors. The powertrain control module (PCM) allows intake manifold vacuum to draw vapors into the combustion chambers during certain operating conditions. The PCM uses the canister purge solenoid to regulate vapor flow.

On 2.5L and 3.3L engines, manifold vacuum purges the vapors at idle as well as off idle. The system is a bi-level purge system. The system uses 2 sources of vacuum remove fuel vapors from the canister.

The 3.0L engine uses a duty cycle purge system. The powertrain control module PCM controls vapor flow by operating the duty cycle EVAP purge solenoid. Refer to Duty Cycle EVAP Purge Solenoid in this section.

The evaporative system uses specially manufactured hoses. If they need replacement, only use fuel resistant hose.

PRESSURE RELIEF/ROLLOVER VALVE

All vehicles have a combination pressure relief and rollover valve. The dual function valve relieves fuel tank pressure. The valve also prevents fuel flow through the fuel tank vent valve hoses should the vehicle rollover. All vehicles pass a 360° rollover.

The pressure relief valve opens at a certain pressure. When fuel tank pressure increases above the calibrated pressure, the valve opens to release fuel tank vapors pressure. The evaporative (charcoal) canister stores the vapors. For pressure relief/rollover valve service, refer to the Fuel Tank section of Group 14.


EVAPORATIVE CANISTER

All vehicles use a sealed, maintenance free, evaporative (charcoal) canister. The canister mounts to the inner wheel well area of the engine compartment (Fig. 2 or Fig. 3).

Fuel tank pressure vents into the canister. The canister temporarily holds the fuel vapors until intake manifold vacuum draws them into the combustion chamber. The canister purge solenoid allows the canister to be purged at predetermined intervals and engine conditions.


EVAP CANISTER PURGE SOLENOID—EXCEPT 3.0L ENGINE

The powertrain control module (PCM) operates the canister purge solenoid (Fig. 4). During warm-up and for a specified period after hot starts, the PCM grounds the purge solenoid causing it to energize. When the PCM grounds the solenoid, vacuum does not reach the charcoal canister valve.



9014-60

Fig. 2 Evaporative Canister—2.5L and 3.3L Engines



9325-44

Fig. 3 Evaporative Canister—3.0L Engine

When the engine reaches a specified operating temperature and the time delay interval has occurred, the PCM de-energizes the solenoid by turning off the ground. When the PCM de-energizes the solenoid, vacuum flows to the canister purge valve. Intake manifold vacuum purges fuel vapors through the throttle body. The PCM also energizes the purge solenoid during certain idle conditions to update the fuel delivery calibration. **Refer to On Board Diagnostics in the General Diagnosis section of Group 14 for test procedures.**

DUTY CYCLE EVAP CANISTER PURGE SOLENOID—3.0L ENGINE

Vehicles equipped with a 3.0L engine use a duty cycle EVAP purge solenoid. The duty cycle EVAP purge solenoid regulates the rate of vapor flow from the EVAP canister to the throttle body. The powertrain control module operates the solenoid.

During the cold start warm-up period and the hot start time delay, the PCM does not energize the solenoid. When de-energized, no vapors are purged. The PCM de-energizes the solenoid during open loop operation.

The engine enters closed loop operation after it reaches a specified temperature and the time delay ends. During closed loop operation, the PCM ener-




Fig. 4 Canister Purge Solenoid

gizes and de-energizes the solenoid approximately 5 to 10 times per second, depending upon operating conditions. The PCM varies the vapor flow rate by changing solenoid pulse width. Pulse width is the amount of time the solenoid energizes. The PCM adjusts solenoid pulse width based on engine air flow.

A rubber boot covers the duty cycle EVAP purge solenoid. On vehicles with 3.0L engines, the solenoid attaches to a bracket mounted to the right engine mount (Fig. 5). The top of the solenoid has the word TOP on it. The solenoid will not operate unless it is installed correctly.




Fig. 5 Duty Cycle EVAP Purge Solenoid—3.0L Engine

PRESSURE-VACUUM FILLER CAP

CAUTION: Remove the fuel filler cap to relieve fuel tank pressure. The cap must be removed prior to disconnecting any fuel system component or servicing the fuel tank.

A pressure-vacuum relief cap seals the fuel tank (Fig. 6). Tightening the cap on the fuel filler tube forms a seal between them. The relief valves in the

cap are a safety feature. They prevent possible excessive pressure or vacuum in the tank. Excessive fuel tank pressure could be caused by a malfunction in the system or damage to the vent lines.

The seal between the cap and filler tube breaks when the cap is removed. Removing the cap breaks the seal and relieves fuel tank pressure.

If the filler cap needs replacement, only use a similar unit.




Fig. 6 Pressure Vacuum Filler Cap

POSITIVE CRANKCASE VENTILATION (PCV) SYSTEMS

Intake manifold vacuum removes crankcase vapors and piston blow-by from the engine. The emissions pass through the PCV valve into the intake manifold where they become part of the calibrated air-fuel mixture. They are burned and expelled with the exhaust gases. The air cleaner supplies make up air when the engine does not have enough vapor or blow-by gases. In this system, fresh air does not enter the crankcase (Figs. 7, 8, 9, 10, 11).




Fig. 7 PCV Valve 2.5L Engine




Fig. 8 PCV Valve 3.0L Engine




Fig. 11 Fresh Air Hose—3.3L Engine PCV System

With the engine idling, remove the PCV valve from its attaching point. If the valve is operating properly, a hissing noise will be heard and a strong vacuum felt when placing a finger over the valve inlet (Fig. 12). With the engine off, shake the valve. The valve should rattle when shaken. Replace the valve if it does not operate properly. **Do not attempt to clean the PCV valve.**




Fig. 9 Fresh Air Hose—3.0L Engine PCV System




Fig. 10 PCV Valve 3.3L Engine




Fig. 12 Typical PCV Test

PCV VALVE TEST

WARNING: APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING ANY TEST OR ADJUSTMENT WITH THE ENGINE OPERATING.

CRANKCASE VENT FILTER

All engines have a crankcase vent filter. The filter cleans outside air before it enters the PCV system. On 2.5L engines, the filter mounts to the upper shell assembly of the air cleaner. On 3.0L engines, it attaches to the inside of the filter element box under the filter element. On the 3.3L engines, the mounts to the bottom of the filter element box. (Refer to Group 0 for mileage intervals and service procedures.)

EXHAUST EMISSION CONTROLS

INDEX

	page		page
EGR Tube Service—3.0L Engines	13	Exhaust Gas Recirculation (EGR) System	11
EGR Tube Service—3.3L Engines	15	Heated Inlet Air System	9
EGR Valve Service—3.0L Engines	13	Heated Oxygen Sensor (O ₂ Sensor)	10
EGR Valve Service—3.3L Engines	15		

HEATED INLET AIR SYSTEM

The 3.0L and 3.3L engines do not have a heated inlet air system.

The 2.5L engine air cleaner has a heated air assembly (Fig. 1). When ambient temperatures are low, the assembly warms the air before it enters the throttle body. The heated air assembly reduces hydrocarbon emissions, improves engine warm-up characteristics and minimizes icing.




Fig. 1 Heated Air Inlet System

The heated air assembly contains a vacuum operated blend door. The blend door opens to either heated air from a stove on the exhaust manifold or ambient air (outside air). A vacuum diaphragm operates the door. A spring opposes the vacuum diaphragm. A temperature sensor controls the vacuum diaphragm (Fig. 2). Adjustment of inlet air temperature occurs only at road load throttle positions or when the intake manifold vacuum exceeds the vacuum diaphragm spring rate.

Air flows through the outside air inlet when ambient air temperature is 8°C (15°F) or more above the air temperature sensor control temperature.

When ambient air temperature falls below the con-




Fig. 2 Heated Air Temperature Sensor

trol temperature, air flows through both the ambient and heated circuits. This occurs after the engine has been started and the exhaust manifold starts to give off heat. Colder ambient air cause greater air flow through the heat stove on the exhaust manifold. Warmer ambient air results in greater ambient air flow through the air cleaner snorkel.

HEATED INLET AIR SYSTEM SERVICE

Heated air inlet system malfunctions may affect driveability and vehicle exhaust emissions.

Use the following procedure to determine if the system functions properly.

(1) Inspect the condition of the heat stove to air cleaner flexible connector and all vacuum hoses. Inspect them for proper attachment. Replace as necessary.

(2) With a cold engine and ambient temperature less than 46°C (115°F.), the heat control door (valve plate) should be in the **up** or **heat on position**.

(3) With the engine warmed up and running, check the air temperature entering the snorkel or at the sensor. When the air temperature entering the outer end of snorkel is 60°C (140°F.) or higher, the door should be in the **down position (heat off)**.

(4) Remove the air cleaner from the engine and allow it to cool down to 46°C (115°F). With 20 inches of vacuum applied to the sensor, the door should be in the **up** or **(heat on position)**. If the door does not

rise to the **heat on** position, check the vacuum diaphragm for proper operation.

(5) To test the diaphragm, apply 20 inches of vacuum to the diaphragm with vacuum pump tool number C-4207 or equivalent (Fig. 3). The diaphragm should not bleed down more than 10 inches of vacuum in 5 minutes. The door should not lift off the bottom of the snorkel at less than 2 inches of vacuum. The door should be in the full **up** position with no more than 4 inches of vacuum.

(6) If the vacuum diaphragm does not perform adequately, replace the heated air assembly.




Fig. 3 Testing Vacuum Diaphragm on Heated Air Inlet Systems

(7) If the vacuum diaphragm performs adequately but proper temperature is not maintained, replace the sensor and repeat the temperature checks in steps 2 and 3.

HEATED AIR TEMPERATURE SENSOR SERVICE

REMOVAL

With air cleaner housing removed from vehicle:

(1) Disconnect vacuum hoses from sensor, remove retainer clips (Fig. 4), and discard (new clips are supplied with a new sensor).

(2) Remove sensor with gasket and discard.

INSTALLATION

(1) Position gasket on the sensor. Install sensor (Fig. 5).

(2) While supporting the sensor on outer diameter, install new retainer clips securely. Ensure the gasket compresses to form an air seal. **Do not attempt to adjust the sensor.**

HEATED OXYGEN SENSOR (O₂ SENSOR)

The O₂ sensor threads into the exhaust manifold. It provides an input voltage to the powertrain control




Fig. 4 Removing Sensor Clips




Fig. 5 Installing Gasket and Sensor

module (PCM). The input tells the PCM the oxygen content of the exhaust gas (Fig. 6, 7 or 8). The PCM uses this information to fine tune the air-fuel ratio by adjusting injector pulse width.




Fig. 6 Oxygen Sensor—2.5L Engine




Fig. 7 Oxygen Sensor—3.0L Engine




Fig. 8 Oxygen Sensor—3.3L Engine

The O₂ sensor produces voltages from 0 to 1 volt, depending upon the oxygen content of the exhaust gas in the exhaust manifold. When a large amount of oxygen is present (caused by a lean air-fuel mixture), the sensor produces a low voltage. When there is a lesser amount present (rich air-fuel mixture) the sensor produces a higher voltage. By monitoring the oxygen content and converting it to electrical voltage, the sensor acts as a rich-lean switch.

The oxygen sensor contains a heating element that keeps it at proper operating temperature during all operating modes. Maintaining correct sensor temperature at all times allows the system to enter into closed loop operation sooner and to remain in closed loop operation during periods of extended idle.

In "Closed Loop" operation the PCM monitors the O₂ sensor input (along with other inputs) and adjusts the injector pulse width accordingly. During "Open Loop" operation the PCM ignores the O₂ sensor input. The PCM adjusts injector pulse width based on preprogrammed (fixed) oxygen sensor input values and the current inputs from other sensors.

REMOVAL

CAUTION: Do not pull on the oxygen sensor wire when disconnecting the electrical connector.

WARNING: THE EXHAUST MANIFOLD MAY BE EXTREMELY HOT. USE CARE WHEN SERVICING THE OXYGEN SENSOR.

- (1) Disconnect oxygen sensor electrical connector.
- (2) Remove sensor using Tool C-4907 (Fig. 9).




Fig. 9 Oxygen Sensor Socket

After removing the sensor, the exhaust manifold threads must be cleaned with an 18 mm X 1.5 + 6E tap. If reusing the original sensor, coat the sensor threads with an anti-seize compound such as Loctite 771-64 or equivalent. New sensors have compound on the threads and do not require an additional coating. Tighten the sensor to 27 N•m (20 ft. lbs.) torque.

EXHAUST GAS RECIRCULATION (EGR) SYSTEM

The 3.0L and 3.3L engines use Exhaust Gas Recirculation (EGR) systems (Fig. 10 or Fig. 11). The EGR system reduces oxides of nitrogen (NO_x) in engine exhaust and helps prevent spark knock. The system allows a predetermined amount of hot exhaust gas to recirculate and dilute the incoming air/fuel mixture. The diluted air/fuel mixture reduces peak flame temperature during combustion.

The EGR system consists of:

- EGR tube (connects a passage in the intake manifold to the exhaust manifold)
- EGR valve
- Electronic EGR Transducer (EET)
- Connecting hoses

The electronic EGR transducer (EET) contains an electrically operated solenoid and a back-pressure transducer (Fig. 12). The powertrain control module (PCM) operates the solenoid. The PCM determines when to energize the solenoid. Exhaust system back-pressure controls the transducer.

When the PCM energizes the solenoid, vacuum does not reach the transducer. Vacuum flows to the transducer when the PCM de-energizes the solenoid.




Fig. 10 EGR System—3.0L Engines




Fig. 11 EGR Mounting—3.3L and 3.8L Engines

When exhaust system back-pressure becomes high enough, it fully closes a bleed valve in the transducer. When the PCM de-energizes the solenoid and back-pressure closes the transducer bleed valve, vacuum flows through the transducer to operate the EGR valve.

De-energizing the solenoid, but not fully closing the transducer bleed hole (because of by low back-pressure), varies the strength of vacuum applied to the EGR valve. Varying the strength of the vacuum changes the amount of EGR supplied to the engine. This provides the correct amount of exhaust gas recirculation for different operating conditions.

This system does not allow EGR at idle. The EGR systems can operate at all temperatures above 60°F.




Fig. 12 Electric EGR Transducer (EET) Assembly

EGR SYSTEM ON-BOARD DIAGNOSTICS

The PCM performs an on-board diagnostic check of the EGR system on all California vehicles with EGR systems. The diagnostic system uses the Electric EGR Transducer (EET) for the system tests.

The diagnostic check activates only during selected engine/driving conditions. When the conditions are met, the PCM energizes the transducer solenoid to disable the EGR. The PCM checks for a change in the oxygen sensor signal. If the air-fuel mixture goes lean, the PCM will attempt to enrichen the mixture. The PCM registers a fault if the EGR system has failed or degraded. After registering a fault, the PCM turns on the malfunction indicator lamp (instrument panel Check Engine lamp). The malfunction indicator lamp indicates the need for immediate service.

If a problem is indicated by the malfunction indicator lamp and a diagnostic trouble code for the EGR system, check for proper operation of the EGR system. Use the System Test, EGR Gas Flow Test and EGR Diagnosis Chart. If the EGR system tests properly, check the system using the DRBII scan tool. Refer to On-Board Diagnosis sections of Group 14. Also, refer to the DRBII scan tool and the appropriate Powertrain Diagnostics Procedure manual.

EXHAUST GAS RECIRCULATION (EGR) SYSTEM TEST

WARNING: APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING EGR SYSTEM TEST.

A failed or malfunctioning EGR system can cause engine spark knock, sags or hesitation, rough idle, and/or engine stalling. To ensure proper operation of the EGR system, all passages and moving parts must

be free of deposits that could cause plugging or sticking. Ensure that the system hoses does not leak. Replace leaking components.

Inspect hose connections between throttle body, intake manifold, EGR solenoid and transducer, and the EGR valve. Replace hardened, cracked, or melted hoses. Repair or replace faulty connectors.

Check the EGR control system and EGR valve with the engine fully warmed up and running (engine coolant temperature over 150°F). With the transmission in neutral and the throttle closed, allow the engine to idle for 70 seconds. Abruptly accelerate the engine to approximately 2000 rpm, but not over 3000 rpm. The EGR valve stem should move when accelerating the engine (the relative position of the groove on the EGR valve stem should change). Repeat the test several times to confirm movement. If the EGR valve stem moves, the control system is operating normally. If the control system is not operating normally, refer to the EGR Diagnosis Chart to determine the cause.

EGR GAS FLOW TEST

The following procedure should be used to determine if exhaust gas is flowing through the EGR system.

Connect a hand vacuum pump to the EGR valve vacuum motor. With engine running at idle speed, slowly apply vacuum. Engine speed should begin to drop when applied vacuum reaches 2.0 to 3.5 inches. Engine speed may drop quickly or engine may even stall. This indicates that EGR gas is flowing through the system.

If both the EGR Gas Flow Check, System Check and Diagnosis Chart are completed satisfactorily, then the EGR system functions normally.

If engine speed does not drop off when performing the test, remove both the EGR valve and EGR tube and check for plugged passages. Also, check the intake manifold inlet passage. Clean or replace these components for restoration of proper flow.

EGR VALVE SERVICE—3.0L ENGINES

The EGR valve and Electrical EGR Transducer (EET) are serviced as an assembly.

REMOVAL

- (1) Disconnect the electric and vacuum connectors from the electric EGR transducer (EET) (Fig. 13).
- (2) Remove EGR valve mounting bolts.
- (3) Clean all gasket surfaces and discard old gas-




Fig. 13 EGR System Service—3.0L Engines

kets. Check for any signs of leakage or cracked surfaces. Repair or replace as necessary.

INSTALLATION

- (1) Install EGR valve and new gasket on intake manifold. Tighten mounting bolts to 22 N•m (200 in. lbs.) torque.
- (2) Connect the electrical and vacuum connectors to the electric EGR transducer.

EGR TUBE SERVICE—3.0L ENGINES

REMOVAL

- (1) Remove EGR tube flange nuts from exhaust manifold (Fig. 13).
- (2) Remove EGR valve nuts at intake manifold (Fig. 13). Remove EGR tube.
- (3) Clean all gasket surfaces and discard old gaskets. Check for any signs of leakage or cracked surfaces. Repair or replace as necessary.

INSTALLATION

- (1) Loosely install the EGR tube on the intake and exhaust manifolds with new gaskets.
- (2) Tighten EGR tube flange bolts at the intake manifold to 22 N•m (200 in. lbs.) torque.
- (3) Tighten EGR tube to exhaust manifold nuts to 22 N•m (200 in. lbs.) torque.

EGR DIAGNOSIS CHART

NOTE: ALL TESTS MUST BE MADE WITH FULLY WARM ENGINE RUNNING CONTINUOUSLY FOR AT LEAST TWO MINUTES.

WARNING: BE SURE TO APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING IDLE CHECK OR ADJUSTMENT, OR ANY ENGINE RUNNING TESTS OR ADJUSTMENTS.

Condition	Possible Cause	Correction
EGR VALVE STEM DOES NOT MOVE ON SYSTEM TEST.	(a) Cracked, leaking, disconnected or plugged hoses.	(a) Verify correct hose connections and leak check and confirm that all hoses are open. If defective hoses are found, replace hose harness. (b) Disconnect hose harness from EGR vacuum transducer and connect auxiliary vacuum supply. Raise engine rpm to 2000 rpm and hold. Apply 10" Hg vacuum while checking valve movement. If no valve movement occurs, replace valve/transducer assy. If valve opens (approx. 3 mm or 1/8" travel), hold supply vacuum to check for diaphragm leakage. Valve should remain open 30 seconds or longer. If leakage occurs, replace valve/transducer assy. If valve is satisfactory, check control system.
EGR VALVE STEM DOES NOT MOVE ON SYSTEM TEST. OPERATES NORMALLY ON EXTERNAL VACUUM SOURCE.	(a) Defective control system— plugged passages. (b) Defective control system— solenoid or solenoid control circuit.	(a) Remove throttle body and inspect port (slot type) in throttle bore and associated passage in throttle body. Use suitable solvent to remove deposits and check for flow with light air pressure. Normal operation should be restored to EGR system. (b) Refer to Group 14, General Diagnosis "On Board Diagnostics" to check solenoid.
ENGINE WILL NOT IDLE. DIES OUT ON RETURN TO IDLE OR IDLE IS VERY ROUGH OR SLOW.	(a) High EGR valve leakage in closed position. (b) EGR tube to intake manifold leak. (c) Solenoid or control signal to solenoid failure.	(a) If removal of vacuum hose from EGR valve does not correct rough idle, (a1) Turn engine off. Remove the air cleaner exposing the inlet to the throttle body. (a2) Disconnect the backpressure hose from the EGR valve. (a3) Using a nozzle with a rubber grommet connection, direct compressed air (50 to 60 psi) down through the steel backpressure tube on the EGR valve while opening and closing the throttle blade. (a4) If the sound from the compressed air changes distinctly in step a3, the poppet is leaking and air is entering the intake manifold. Replace the EGR valve. (b) Remove tube and visually inspect tube seal on gasket. Tube end should be uniformly indented on gasket with no signs of leak. If signs of exhaust gas leakage are present, replace gaskets and tighten flange nuts to 23 N·m (200 in. lbs.). If an intake plenum leak persists, replace EGR tube and gaskets, following installation instructions. (c) Verify correct hose connections and leak check and confirm that all hoses are open. If defective hoses are found, replace hose harness. (c1) Refer to Group 14, General Diagnosis "On Board Diagnostics" to check solenoid.

NOTE: DO NOT ATTEMPT TO CLEAN BACKPRESSURE EGR VALVE, REPLACE ENTIRE VALVE/TRANSDUCER ASSEMBLY IF NECESSARY.

EGR VALVE SERVICE—3.3L ENGINES

The EGR valve and Electrical EGR Transducer (EET) are serviced as an assembly.

REMOVAL

- (1) Disconnect vacuum tube from electric EGR transducer (EET). Inspect vacuum tube for damage (Fig. 14).
- (2) Remove electrical connector from EET.
- (3) Remove EGR valve bolts from intake manifold.
- (4) Open EGR transducer clip and remove electric EGR transducer.
- (5) Remove EGR valve from intake manifold.
- (6) Clean gasket surface and discard old gasket. Check for any signs of leakage or cracked surfaces. Repair or replace as necessary.


INSTALLATION

- (1) Assemble EGR valve with new gasket onto the intake manifold.
- (2) Install mounting bolts. Tighten bolts to 22 N•m (200 in. lbs.) torque.
- (3) Install electric EGR transducer in clip with orientation tab in slot and snap closed.
- (4) Reconnect vacuum hose and electrical connector to EET.

EGR TUBE SERVICE—3.3L ENGINES

REMOVAL

- (1) Remove EGR tube attaching bolts from intake and exhaust manifolds.



9025-22X

Fig. 14 EGR System—3.3L Engines

- (2) Clean intake and exhaust manifold gasket surfaces. Discard old gasket.
- (3) Check for signs of leakage or cracked surfaces on either manifolds or tube. Repair or replace as necessary.

INSTALLATION

- (1) Loosely assemble EGR tube and new gaskets into place on intake and exhaust manifolds.
- (2) Tighten mounting bolts to 22 N•m (200 in. lbs.) torque.

