

## COMPONENT AND SYSTEM INDEX

Name	Group-page	Name	Group-page
AUDIO SYSTEM . . . . .	8F-1	SERVICE PROCEDURES . . . . .	11-4
BATTERY/STARTER/ALTERNATOR SERVICE . . . . .	8B-1	TORQUE SPECIFICATION . . . . .	11-17
ALTERNATOR SERVICE PROCEDURES . . . . .	8B-8	FRAME AND BUMPERS . . . . .	13-1
BATTERY . . . . .	8B-1	FRONT SUSPENSION AND DRIVE SHAFTS . . . . .	2-1
SPECIFICATIONS . . . . .	8B-10	DRIVESHAFTS . . . . .	2-26
STARTER . . . . .	8B-3	FRONT SUSPENSION . . . . .	2-2
BATTERY/STARTING/CHARGING SYSTEMS		FRONT SUSPENSION SERVICE PROCEDURES . . . . .	2-6
DIAGNOSTICS . . . . .	8-1	GENERAL INFORMATION . . . . .	2-1
ALTERNATOR TEST PROCEDURES ON VEHICLE . . . . .	8-15	SPECIFICATIONS . . . . .	2-46
BATTERY TEST PROCEDURES ON-VEHICLE . . . . .	8-2	FUEL SYSTEM . . . . .	14-1
FAULT CODES—ON BOARD DIAGNOSTICS . . . . .	8-18	2.5L SINGLE POINT FUEL INJECTION—GENERAL	
GENERAL INFORMATION . . . . .	8-1	DIAGNOSIS . . . . .	14-34
IGNITION OFF DRAW (IOD) . . . . .	8-7	2.5L SINGLE POINT FUEL INJECTION—SERVICE	
SPECIFICATIONS . . . . .	8-23	PROCEDURES . . . . .	14-45
STARTER TEST PROCEDURES ON VEHICLE . . . . .	8-9	2.5L SINGLE POINT FUEL INJECTION—SYSTEM	
BODY . . . . .	23-1	OPERATION . . . . .	14-22
BODY COMPONENT SERVICE . . . . .	23-20	3.0L MULTI-POINT FUEL INJECTION—GENERAL	
BODY DIAGNOSTIC PROCEDURES . . . . .	23-2	DIAGNOSIS . . . . .	14-64
GENERAL SERVICE INFORMATION . . . . .	23-1	3.0L MULTI-POINT FUEL INJECTION—SERVICE	
PAINT . . . . .	23-4	PROCEDURES . . . . .	14-75
SEAT COMPONENT SERVICE . . . . .	23-7	3.0L MULTI-POINT FUEL INJECTION—SYSTEM	
WINDSHIELD . . . . .	23-5	OPERATION . . . . .	14-52
BRAKES . . . . .	5-1	3.3L MULTI-POINT FUEL INJECTION—GENERAL	
ANTI-LOCK BRAKE SYSTEM (BENDIX ANTI-LOCK		DIAGNOSIS . . . . .	14-93
10 AS BODY FWD/AWD) . . . . .	5-56	3.3L MULTI-POINT FUEL INJECTION—SERVICE	
BRAKE DIAGNOSIS . . . . .	5-15	PROCEDURES . . . . .	14-105
BRAKE DISC (ROTOR) . . . . .	5-42	3.3L MULTI-POINT FUEL INJECTION—SYSTEM	
DISC BRAKES . . . . .	5-33	OPERATION . . . . .	14-81
DRUM BRAKES . . . . .	5-20	ACCELERATOR PEDAL AND THROTTLE CABLE . . . . .	14-20
GENERAL INFORMATION . . . . .	5-1	FUEL DELIVERY SYSTEM . . . . .	14-3
HYDRAULIC SYSTEM CONTROL VALVES . . . . .	5-28	FUEL TANK . . . . .	14-13
KELSEY HAYES DOUBLE PIN FAMILY CALIPER . . . . .	5-35	GENERAL INFORMATION . . . . .	14-1
MASTER CYLINDER . . . . .	5-49	SPECIFICATIONS . . . . .	14-113
PARKING BRAKES . . . . .	5-46	HEATING AND AIR CONDITIONING . . . . .	24-1
POWER BRAKES . . . . .	5-51	AUXILIARY REAR HEATING OR	
SERVICE ADJUSTMENTS . . . . .	5-3	HEATING-AIR/CONDITIONING . . . . .	24-50
SERVICE PROCEDURES . . . . .	5-31	COMPONENT DIAGNOSIS . . . . .	24-38
SPECIFICATIONS . . . . .	5-90	COMPONENT SERVICE PROCEDURES . . . . .	24-41
WHEEL BEARINGS . . . . .	5-54	FIXED DISPLACEMENT COMPRESSOR AND COMPONENTS	
WHEEL CYLINDERS . . . . .	5-26	DIAGNOSTIC PROCEDURES . . . . .	24-13
CHIME WARNING/REMINDER SYSTEM . . . . .	8-1	GENERAL INFORMATION . . . . .	24-1
COOLING SYSTEM . . . . .	7-1	HEATER AND A/C PERFORMANCE TESTS . . . . .	24-19
ACCESSORY DRIVE BELTS . . . . .	7-23	REFRIGERANT SERVICE PROCEDURES . . . . .	24-22
ENGINE BLOCK HEATER . . . . .	7-27	VACUUM CONTROL SYSTEM DIAGNOSIS . . . . .	24-18
GENERAL INFORMATION . . . . .	7-1	VARIABLE COMPRESSOR AND COMPONENTS	
SERVICE PROCEDURES . . . . .	7-10	DIAGNOSTIC PROCEDURES . . . . .	24-4
SPECIFICATIONS . . . . .	7-29	VARIABLE DISPLACEMENT COMPRESSOR SERVICE	
ELECTRICAL . . . . .	8-1	PROCEDURES . . . . .	24-27
GROUP INDEX . . . . .	8-1	HORNS . . . . .	8G-1
EMISSION CONTROL SYSTEMS . . . . .	25-1	IGNITION SYSTEMS . . . . .	8D-1
EVAPORATIVE EMISSION CONTROLS . . . . .	25-2	2.5L AND 3.0L IGNITION SYSTEMS—DIAGNOSTIC	
EXHAUST EMISSION CONTROLS . . . . .	25-8	PROCEDURES . . . . .	8D-10
ENGINE . . . . .	9-1	2.5L AND 3.0L IGNITION SYSTEMS—SERVICE	
2.5L ENGINE . . . . .	9-8	PROCEDURES . . . . .	8D-13
3.0L ENGINE . . . . .	9-50	2.5L AND 3.0L IGNITION SYSTEMS—SYSTEM	
3.3L ENGINE . . . . .	9-82	OPERATION . . . . .	8D-1
STANDARD SERVICE PROCEDURES . . . . .	9-1	3.3L IGNITION SYSTEM—DIAGNOSTIC	
EXHAUST SYSTEM AND INTAKE MANIFOLD . . . . .	11-1	PROCEDURES . . . . .	8D-32
GENERAL INFORMATION . . . . .	11-1	3.3L IGNITION SYSTEM—SYSTEM OPERATION . . . . .	8D-25

3.3L IGNITION SYSTEMS—SERVICE	
PROCEDURES . . . . .	8D-35
IGNITION SWITCH . . . . .	8D-40
SPECIFICATIONS . . . . .	8D-42
INSTRUMENT PANEL AND GAUGES . . . . .	8E-1
INTRODUCTION . . . . .	Intro.-1
LAMPS . . . . .	8L-1
BULB APPLICATION TABLE . . . . .	8L-11
EXTERIOR LAMPS, SWITCHES AND SYSTEMS . . . . .	8L-2
GENERAL INFORMATION . . . . .	8L-1
ILLUMINATED ENTRY SYSTEM . . . . .	8L-9
LUBRICATION AND MAINTENANCE . . . . .	0-1
CHASSIS AND BODY . . . . .	0-19
DRIVETRAIN . . . . .	0-15
ENGINE . . . . .	0-8
GENERAL INFORMATION . . . . .	0-1
MANUAL TRANSAXLE CLUTCH . . . . .	6-1
OVERHEAD CONSOLE . . . . .	8C-1
POWER LOCKS . . . . .	8P-1
POWER MIRRORS . . . . .	8T-1
POWER SEATS . . . . .	8R-1
POWER WINDOWS . . . . .	8S-1
REAR SUSPENSION AND DRIVELINE . . . . .	3-1
ALL WHEEL DRIVE REAR SUSPENSION . . . . .	3-5
REAR DRIVE LINE MODULE ASSEMBLY (ALL WHEEL DRIVE) . . . . .	3-9
REAR DRIVE LINE MODULE ASSEMBLY SERVICE PROCEDURES . . . . .	3-11
REAR DRIVE LINE MODULE VACUUM ACTUATION DIAGNOSIS . . . . .	3-37
SPECIFICATIONS . . . . .	3-42
TWO WHEEL DRIVE REAR SUSPENSION . . . . .	3-1
REAR WINDOW DEFOGGER . . . . .	8N-1
RESTRAINT SYSTEMS . . . . .	8M-1
SPEED CONTROL SYSTEM . . . . .	8H-1
STEERING . . . . .	19-1
ACUSTAR STANDARD AND TILT STEERING COLUMN . . . . .	19-28

GENERAL INFORMATION . . . . .	19-1
POWER STEERING GEAR . . . . .	19-20
POWER STEERING PUMPS . . . . .	19-2
SPECIFICATIONS AND TIGHTENING REFERENCE . . . . .	19-35
TRANSAXLE . . . . .	21-141
4 SPEED ELECTRONIC TRANSAXLE HYDRAULIC SCHEMATICS . . . . .	21-184
4-SPEED ELECTRONIC AUTOMATIC TRANSAXLE . . . . .	21-82
4-SPEED ELECTRONIC TRANSAXLE ON-BOARD DIAGNOSTICS . . . . .	21-157
A-523 MANUAL TRANSAXLE . . . . .	21-1
ALL WHEEL DRIVE POWER TRANSFER UNIT (P.T.U.) . . . . .	21-141
THREE SPEED TRANSAXLE HYDRAULIC SCHEMATICS . . . . .	
SPECIFICATIONS . . . . .	21-197
THREE SPEED TORQUEFLITE AUTOMATIC TRANSAXLE . . . . .	21-32
TURN SIGNALS AND HAZARD WARNING FLASHER . . . . .	8J-1
WHEELS TIRES . . . . .	22-1
SPECIFICATIONS . . . . .	22-8
TIRE SERVICE PROCEDURES . . . . .	22-1
WHEEL SERVICE PROCEDURES . . . . .	22-6
WINDSHIELD WIPER AND WASHER SYSTEMS . . . . .	8K-1
INTERMITTENT WINDSHIELD WIPER MOTOR AND SWITCH . . . . .	8K-7
REAR WINDOW WIPER/WASHER SYSTEM . . . . .	8K-10
WINDSHIELD WASHERS . . . . .	8K-9
WINDSHIELD WIPER BLADE AND ARM . . . . .	8K-1
WINDSHIELD WIPER MOTOR AND LINKAGE . . . . .	8K-4
WIRING DIAGRAMS . . . . .	8W-1
COMPONENT IDENTIFICATION . . . . .	8W-11
GENERAL INFORMATION . . . . .	8W-1
SPLICE LOCATION . . . . .	8W-33
WIRING DIAGRAMS AS-BODY H-K . . . . .	8W-47